



Onboard CO₂ plate freezing with cold thermal energy storage

By Espen Verpe, SINTEF Energy Research



Agenda

01

Background

02

Method and
materials

03

Numerical
freezing

04

Results

05

Cold thermal
energy
storage
(CTES)

06

Summary
and
conclusion





Background

- Ammonia and CO₂ is a popular choice, however **CO₂** has the advantage of **lower evaporating temperature**
- Higher temperature difference decreases system COP, but results in **faster freezing rates**
- **Cold energy storages** is proven to be beneficial in residential refrigeration. Does it also apply for the freezing industry?

Problem statement



How are freezing systems influenced by lower evaporating temperatures, down to -50°C ?


Can they be improved by implementing CTES?

Method

- Develop numerical freezing models
- Validate the model
- Develop refrigeration system model
- Define and calculate KPIs:
 - Specific energy use $\left[\frac{\text{kJ}}{\text{kg fish}} \right]$
 - Freezer capacity $\left[\frac{\text{kg fisk}}{\text{day}} \right]$
- How are the KPIs influenced by CTES?








Numerical freezing model


- MATLAB based
- Solves the 2D heat equation
 - Updating thermophysical properties
 - Includes phase change
- Allow us to freeze different dimensions and different evaporating temperatures
- Was validated in an industrial plate freezer



Temperature in fish block during freezing



Time = 20 seconds

Core temperature in fish block during freezing









Results


- Freezing times are reduced
- Increase in energy use
- Most important: Increase in production capacity

		Freezing time [min]			Energy use [kWh/ton]			Production capacity [kg/h]		
		-50 °C	-40 °C	-30 °C	-50 °C	-40 °C	-30 °C	-50 °C	-40 °C	-30 °C
Evaporating temperature										
Block thickness [mm]	50	19 %	23 %	31 %	149 %	108 %	81 %	188 %	161 %	126 %
	75	36 %	45 %	61 %	156 %	122 %	90 %	177 %	146 %	111 %
	100	58 %	73 %	100 %	172 %	133 %	100 %	166 %	134 %	100 %


Heat load vs freezing capacity

Q.T. Pham (2002)








Temperature in flash tank




CTES






Heat load and compressor capacity with CTES

- The CTES system helps the compressor to remove gas from the receiver in the beginning
- CTES tank is charged when compressor capacity is larger than the heat load
- Lower temperature increase in the receiver during freezer
- More stable compressor run



Heat load and compressor capacity with CTES

- The CTES system helps the compressor to remove heat from the receiver in the



- increase in the receiver during freezer
- More stable compressor run



Summary and Conclusion

- Freezing in plate freezers is well modelled
- Higher capacity with lower evaporating temperature
- CTES can be used to reduce the receiver temperature spike during initial freezing and therefore additionally reduce freezing time
- Economically important to increase product capacity



Thank you for your attention!

